


840 x 148.5 mm



www.bluestork.eu

A doubt, a question? Do not hesitate to contact us:

Un doute, une question? N'hésitez pas à nous contacter :

¿Tiene alguna duda o pregunta? No dude en ponerse en contacto con nosotros:

Haben Sie Zweifel oder eine Frage? Zögern Sie nicht, uns zu kontaktieren:

Twijfels of vragen? Aarzel dan niet om contact met ons op te nemen:

support@axs-group.com




PLUG & PLAY



Does not require any driver, is automatically recognized by your system.
 Ne nécessite aucun driver, est reconnu automatiquement par votre système.
 No requiere ningún controlador, es reconocido automáticamente por su sistema.
 Non richiede driver e viene riconosciuto automaticamente dal sistema.
 Benötigt keinen Treiber, wird automatisch von Ihrem System erkannt.
 Vereist geen stuurprogramma en wordt automatisch herkend door je systeem.



A	Charging indicator / Indicateur de charge / Indicador de carga / Ladezustandsanzeige / Oplaadindicator /
B	Fn lock / Verrouillage des touches de fonction / Bloqueo de teclas de función / Funktionstasten sperren / Functie toetsvergrendeling
C	Num lock / Verrouillage du pavé numérique / Bloqueo del teclado / Sperren des Nummernblocks / Toetsenbordvergrendeling
D	Caps lock / Verrouillage des majuscules / Bloqueo de mayúsculas / Großbuchstaben sperren / Caps lock
E	Power indicator / Indicateur de marche / Indicador de encendido / Leistungsanzeige / Voedingsindicator
F	Power switch / Bouton on/off / Botón de encendido/apagado / Ein/Aus-Taste / Aan/uit-knop
G	USB-C charging port / Prise de charge USB-C / Puerto de carga USB-C / USB-C-Ladeanschluss / USB-C oplaadpoort



The nano receiver is stored in the mouse.
 Le nano récepteur est rangé dans la souris.
 El nano receptor se almacena en el ratón.
 Der Nano-Empfänger wird in der Maus aufbewahrt.
 De nano-ontvanger is opgeslagen in de muis.

H	Left clic / Clic gauche / Clic izquierdo / Linksklick / Klik links
I	Right clic / clic droit / Clic derecho / Rechtsklick / Klik rechts
J	Scroll wheel / Molette / Rueda de desplazamiento / Scrollrad / Scrollwiel
K	Previous / Précédent / Anterior / Vorherige / Vorige
L	Next / Suivant / Siguiente / Weiter / Volgende
M	DPI switch / Commutateur DPI / Interruptor DPI / DPI-Schalter / DPI-schakelaar
N	USB dongle / Transmetteur USB / Mochilo USB / USB-Dongle / USB-Dongle


MULTIMEDIA SHORCUTS / RACCORCI MULTIMEDIA / ATAJOS DIRECTOS MULTIMEDIA / MULTIMEDIA-VERKNÜPFUNGEN / MULTIMEDIA SNELKOPPELINGEN

- Mute / Silence / Silencio / Stille / Stille
- Volume - / Volumen - / Band -
- Volume + / Volumen + / Band +
- Previous / Précédent / Anterior / Vorherige / Vorige
- Play/Pause / Lecture/Pause / Reproducir/Pausa / Wiedergabe/Pause / Afspele/Pauze
- Next / Suivant / Siguiente / Weiter / Volgende
- Brightness - / Luminosité - / Brillo - / Helligkeit - / Helderheid -
- Brightness + / Luminosité + / Brillo + / Helligkeit + / Helderheid +
- Folders / Explorateur de fichiers / Explorador de archivos / Datei-Explorer / Bestandsverkenner
- Internet
- Fn lock / Verrouillage Fn / Bloqueo Fn / FN-Sperre / FN-slot
- Search / Recherche / Búsqueda / Suche / Zoek op
- Personal assistant / Assistant personnel / Asistente personal / Persönliche Assistentin / Persoonlijk assistent
- Connection / Connexion / Conexión / Verbindung / Connessione
- Settings / Paramètres / Ajustes / Einstellungen / Instellingen

z2 The keyboard and the mouse enter sleep mode after 8 minutes idle.
 Le clavier et la souris passent en mode veille après 8 minutes d'inactivité.
 El teclado y el ratón entran en modo de reposo tras 8 minutos inactivos.
 Die Tastatur und die Maus gehen nach 8 Minuten Leerlauf in den Ruhezustand über.
 Het toetsenbord en de muis gaan in de slaapmodus nadat ze 8 minuten niet zijn gebruikt.

TECHNICAL SPECIFICATIONS / SPÉCIFICATIONS TECHNIQUES / ESPECIFICACIONES TÉCNICAS / TECHNISCHE SPECIFIKATIES

Connection / Connexion / Conexión / Verbindung / Connessione	2.4 Ghz
Operating range / Distance de connexion / Distancia de conexión / Verbindungsentfernung / Verbindingsafstand	10 m
Key / Touches / Teclas / Tasten / Toetsen	Cisrs / Ciseaux / Tijeras / Schere / Schaar
Lifespan / Durée de vie / Vida útil / Lebensdauer / Levensduur	3 Million strokes / frappes / puñaciones / Anschläge / Berorertes
Mouse DPI / Niveaux de DPI de la souris / DPI del ratón / Maus DPI / Muis DPI	800 / 1200 / 1600
Charging time / temps de charge / Tiempo de carga / Aufladezeit / Oplaadtijd	2 h
Capacity / Capacité / Capacidad / Kapazität / Capaciteit	Clavier/Keyboard/Teclado : 280 mAh Souris/Mouse/ratón : 300 mAh ~90h



Minimum Charging Power / Puissance de charge minimale	0.1 W
Maximum Charging Power / Puissance de charge maximale	1 W
No charging Protocole / Pas de protocole de charge	
Charger not included / Chargeur non inclus	

COMBO GRAPHEME

Manuel d'utilisation



WIRELESS MOUSE & KEYBOARD



BLUESTORK COMBO GRAPHEME ©2026
 Made in China
 Distribué par :
 AXS - 1 Rue de la Garenne ZI Le Vert Galant
 95310 SAINT OUEN L'AUMONE - France

DÉCLARATION DE CONFORMITÉ UE

AXS déclare sous sa seule responsabilité en tant que fabricant que le produit ci-dessous :

Ensemble souris et clavier sans fil Bluestork
 PACK-WL-PC-BK/FR EAN 3760162065657

Est conforme aux exigences et normes essentielles suivantes :

UE directives	Conforms to
UK CA - RED	EN 62479 :2010 BS EN 62479 :2010 BS EN 50663 :2017 BS EN 62368-1 :2014+A11 :2017 ETSI EN 301 489-1 V2.2.3 (2019-11) ETSI EN 301 489-17 V3.2.4 (2020-09) ETSI EN 300 328 V2.2.2 (2019-07)
CE DIRECTIVE 2014/53/EU	EN 62368-1 :2014+A11 :2017 EN 62479 :2010 ETSI EN 301 489-1 V2.2.1 (2019-03) ETSI EN 301 489-3 V2.1.1 (2019-03) EN 55032 :2015+A11 :2020 EN 55035 :2017+A11 :2020 EN 61000-3-2 :2014 EN 61000-3-3 :2013 ETSI EN 300 440 V2.2.1 (2018-07)

Et dont la bande de fréquences de transmission est la suivante :
 Fréquence Minimale : 2403,85 Mhz / Fréquence Maximale : 2479,85 Mhz
 EIRP max : -61,13 dBm, EIRP mini : -90,29 dBm

Fait à SAINT OUEN L'AUMONE, le 4 mai 2026
 Par Stefan Riesser
 Président AXS

CONSIGNES DE SÉCURITÉ

Débranchez le produit avant nettoyage. Utilisez un chiffon doux et sec. N'utilisez pas de produits liquides ou aérosols.
 En cas d'odeur anormale, de surchauffe, de fumée ou de dysfonctionnement, débranchez immédiatement le produit et contactez le service après-vente.
 Si un liquide ou un corps étranger pénètre dans le produit, éteignez-le, débranchez-le et retirez-le si possible.
 Ne démontez pas et ne modifiez pas le produit. Les réparations doivent être effectuées par un professionnel qualifié. Toute modification non autorisée annule la garantie.

SÉCURITÉ DES BATTERIES ET DE L'ALIMENTATION (SI APPLICABLE) Général

Si le produit utilise des piles ou une batterie rechargeable :

Tenir hors de portée des enfants. En cas d'ingestion, consulter immédiatement un médecin.
 Ne pas utiliser de batterie endommagée ou qui fuit.
 Ne pas court-circuiter les bornes.
 Ne pas écraser, percer, démonter ou exposer au feu.
 Ne pas jeter avec les déchets ménagers.

Piles non rechargeables (si applicable)

Ne pas tenter de recharger des piles non rechargeables.
 Respecter la polarité (+/-).
 Retirer les piles en cas de non-utilisation prolongée.

Batterie rechargeable (si applicable)

Utiliser uniquement la batterie fournie ou recommandée.
 Ne pas remplacer la batterie soi-même sauf indication explicite.
 Un remplacement incorrect peut entraîner un risque d'explosion ou d'incendie.
 Ne pas exposer à une chaleur excessive (soleil, feu, etc.).
 Ne pas exposer à des températures extrêmes.
 Respecter les conditions d'utilisation, stockage et transport spécifiées.

Recharge (si applicable)

Utiliser uniquement le système de charge fourni ou approuvé.

GARANTIE

Garantie de 2 ans à compter de la date d'achat contre les défauts de fabrication.

Non couvert :

mauvaise utilisation
 dommages électriques ou mécaniques
 réparations non autorisées
 usure normale et consommables (dont batteries)

Facture obligatoire. Garantie valable dans le pays d'achat.

AXS se réserve le droit de réparer ou remplacer le produit.

Les droits légaux applicables restent en vigueur.

ENVIRONNEMENT Produit (DEEE)

Directive 2012/19/UE
 Ne pas jeter avec les déchets ménagers. Collecte séparée obligatoire.

Batteries (si applicable)

Directive 2006/66/CE
 Règlement (UE) 2023/1542
 À déposer dans des points de collecte dédiés.

Emballage

À trier selon les règles locales.

BLUESTORK COMBO GRAPHEME ©2026
 Made in China
 Distributed by :
 AXS - 1 Rue de la Garenne ZI Le Vert Galant
 95310 SAINT OUEN L'AUMONE - France

EU DECLARATION OF CONFORMITY

AXS declares under its sole responsibility as manufacturer that the product below:

Combo wireless mouse & keyboard - Bluestork
 PACK-WL-PC-BK/FR EAN 3760162065657

Conforms to the following essential requirements and standards:

Directives UE	Conforme suivant
UK CA - RED	EN 62479 :2010 BS EN 62479 :2010 BS EN 50663 :2017 BS EN 62368-1 :2014+A11 :2017 ETSI EN 301 489-1 V2.2.3 (2019-11) ETSI EN 301 489-17 V3.2.4 (2020-09) ETSI EN 300 328 V2.2.2 (2019-07)
CE DIRECTIVE 2014/53/EU	EN 62368-1 :2014+A11 :2017 EN 62479 :2010 ETSI EN 301 489-1 V2.2.1 (2019-03) ETSI EN 301 489-3 V2.1.1 (2019-03) EN 55032 :2015+A11 :2020 EN 55035 :2017+A11 :2020 EN 61000-3-2 :2014 EN 61000-3-3 :2013 ETSI EN 300 440 V2.2.1 (2018-07)

And whose transmission frequency band is:
 Minimal frequency : 2403,85 Mhz / Maximal frequency : 2479,85 Mhz
 EIRP max : -61,13 dBm, EIRP mini : -90,29 dBm

Signed at SAINT OUEN L'AUMONE, DATE May 4th 2026
 By Stefan Riesser
 President AXS

SAFETY INSTRUCTIONS

Disconnect the product before cleaning. Use a dry, soft cloth. Do not use liquid or aerosol cleaners.
 If the product emits unusual odor, heat, smoke, or shows signs of malfunction, disconnect it immediately and contact customer support.
 If liquid or foreign objects enter the product, switch it off, unplug it, and remove the substance if possible.
 Do not open, disassemble, or modify the product. Repairs must be carried out by qualified personnel only. Unauthorized modifications void the warranty.

BATTERY AND POWER SAFETY (IF APPLICABLE) General

If the product uses batteries or a rechargeable battery:

Keep batteries out of reach of children. If swallowed, seek medical advice immediately.
 Do not use damaged or leaking batteries.
 Do not short-circuit terminals.
 Do not crush, puncture, disassemble, or expose batteries to fire.
 Do not dispose of batteries in household waste.

Non-rechargeable batteries (if applicable)

Do not attempt to recharge non-rechargeable batteries.
 Insert batteries respecting polarity (+/-).
 Remove batteries if the product will not be used for a long period.

Rechargeable battery (if applicable)

Use only the battery supplied or specified by the manufacturer.
 Do not replace the battery yourself unless explicitly stated.
 Incorrect replacement may cause explosion or fire.
 Do not expose the product or battery to excessive heat (sunlight, fire, etc.).
 Do not expose the product to extreme temperatures.
 Use, storage and transport must remain within specified temperature limits.

Charging (if applicable)

Use only the supplied or approved charging system.

WARRANTY

This product is covered by a 2-year limited warranty from the date of purchase against manufacturing defects.

The warranty does not cover:

misuse or improper use
 mechanical or electrical damage
 unauthorized repair or modification
 normal wear and consumables (including batteries)

Proof of purchase is required. Warranty valid only in the country of purchase.

AXS reserves the right to repair or replace the product.

Statutory rights under applicable national law are not affected.

ENVIRONMENT

Product (WEEE)

Directive 2012/19/UE
 This product must not be disposed of with household waste.
 It must be collected separately for recycling.

Batteries (if applicable)

Directive 2006/66/EC
 Règlement (UE) 2023/1542
 Batteries must be disposed of at designated collection points.

Packaging

Dispose of packaging according to local recycling regulations.